


Quick start guide

for models DS3111-2/TM3111-2

Telephone base & charger installation

We recommend that you install the telephone base away from any electronic equipment and appliances such as personal computers, computer routers, television sets, microwave ovens or refrigerators. Avoid excessive heat, cold, dust or moisture. Install the telephone base and charger as illustrated. Make sure that the electrical outlet is not controlled by a wall switch. If you subscribe to Digital Subscriber Line (DSL) high-speed Internet service through your telephone line, you must have a DSL filter between the telephone base and the telephone wall jack. The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.





Battery installation & charging

Install the handset battery by following these steps:

1. Press the tab and slide the battery compartment cover down.
2. Align the two holes of the battery plug with the socket pins in the handset battery compartment, matching the red and black wires of the color-coded label.
3. Place the battery in the compartment with the wires in the lower right corner.
4. Align the cover flat against the battery compartment, then slide it up until it clicks into place.

For optimal performance, we recommend that you charge the handset for 16 hours. You can keep the battery charged by returning the handset to the telephone base or charger after use. When the battery power is fully depleted, a full recharge takes about 16 hours.



NOTE:

You must program your voicemail buttons before you can access all of the functions available with your voicemail.

Voicemail setup

If you subscribe to voicemail service provided by your local telephone company, this feature allows you to use the **VOICEMAIL**, **PLAY**, **SKIP** and **ERASE** buttons to access your voicemail. Before completing these steps, be sure to have your access number and password (provided by your local telephone company) to access your voicemail. You will also need the codes to play, skip and erase your messages. Contact your local telephone company for more information.

To program the **ACCESS NUMBER** button:

1. Press **MENU/SELECT** when the handset is not in use.
2. Press **▲** or **▼** to select **VOICEMAIL SETUP**, then press **MENU/SELECT**.
3. Press **▲** or **▼** to select **ACCESS NUMBER**, then press **MENU/SELECT**.
4. Use the dial pad to enter the access number. Press **MUTE/REMOVE** to delete characters if necessary.
5. Press **MENU/SELECT**. You will hear a confirmation tone.

To program the **PASSWORD**, **PLAY**, **SKIP** and **ERASE** buttons, follow steps 1 and 2 above. Next, select the command you wish to program, and press **MENU/SELECT**. Use the dial pad to enter the corresponding code for that command, and press **MENU/SELECT** to confirm.


To program a pause (for more details, refer to the user's manual):

1. Press **MENU/SELECT** when the handset is not in use.
2. Press **▲** or **▼** to select **VOICEMAIL SETUP**, then press **MENU/SELECT** twice.
3. The blinking cursor should be at the end of your access number. Press and hold the **REDIAL/PAUSE** button until a **P** appears.
4. Press **MENU/SELECT**. You will hear a confirmation tone.

Make, receive and end calls

Make a call

- Press **TALK/FLASH** or **OFF**, listen for a dial tone, then dial the telephone number.




-OR-

1. Dial the number (press **MUTE/REMOVE** to make corrections; press and hold REDIAL/PAUSE to insert a dialing pause).
2. Press **TALK/FLASH** or **OFF** to use the speakerphone.

Receive a call

- Press **TALK/FLASH**, **OFF** or any dialing keys (**0-9**, ***** or **#**) to answer an incoming call.



End a call

- Press **OFF/CLEAR** or put the handset back in the telephone base or charger.

NOTES:

1. Use only the power adapters and batteries supplied with your VTech telephone.
2. For complete feature instructions, please refer to your user's manual.

IMPORTANT!

If your product is not working properly:

- Refer to the **Troubleshooting** section of the user's manual.
- Visit our website at www.vtechphones.com. In Canada, go to www.vtechcanada.com.
- Call our customer service at 1 (800) 595-9511. In Canada, call 1 (800) 267-7377.